





# MINIMIZE NAIL POPS

Nail “pop” or “backout” describes the protrusion of nail heads above the surface some time after they were originally driven into the wood (Figure 1). This sometimes happens when green (wet) lumber shrinks because of drying. The nail point stays put while the lumber shrinks along the shank, exposing the nail head.

Repeated wetting and drying of the wood may also cause “cumulative pop” (the nail backs out of the wood incrementally). Staples can also “pop” or “back-out” under these conditions.

1. The best way to minimize nail or staple pop is to use dry lumber or engineered wood framing such as I-joists, trusses, glulams, or structural composite lumber, which is manufactured in a dry condition. Remember that even kiln-dried lumber still has enough water left in it to cause some shrinkage.

2. When attaching plywood underlayment to a subfloor (Figure 2), use nails having a length approximately equal to the total thickness of the subfloor and underlayment layers. If pneumatically driven nails or staples are used, foot pressure should be applied near the fastener to assure contact between the underlayment and subfloor. Do not overdrive or underdrive fasteners, which could result in “telegraphing” fastener or panel joint location through resilient tile or sheet flooring.



3. Use of deformed-shank nails or proprietary plastic coated (not cement coated) fasteners may help reduce cumulative pop.

4. When attaching wood structural panel roof or floor sheathing, the framing surface should be clean, level and flush. If framing hangers or connectors are attached to the top of supporting framing

members, shims or furring strips made from wood structural panels may need to be placed between these hardware components, to make the framing surface flush. Otherwise, gaps between the sheathing and framing could result in nail pops when the sheathing is subjected to construction loads or foot traffic.

We have field representatives in most major U.S. cities and in Canada who can help answer questions involving APA trademarked products. For additional assistance in specifying engineered wood products, contact us:

**APA – THE ENGINEERED  
WOOD ASSOCIATION  
HEADQUARTERS**

7011 So. 19th St. • P.O. Box 11700  
Tacoma, Washington 98411-0700  
(253) 565-6600 • Fax: (253) 565-7265

(International Offices:  
Bournemouth, United Kingdom;  
Mexico City, Mexico; Tokyo, Japan.)



**www.apawood.org**

**PRODUCT SUPPORT HELP DESK**

(253) 620-7400  
E-mail Address: [help@apawood.org](mailto:help@apawood.org)

*The product use recommendations in this publication are based on APA – The Engineered Wood Association's continuing programs of laboratory testing, product research, and comprehensive field experience. However, because the Association has no control over quality of workmanship or the conditions under which engineered wood products are used, it cannot accept responsibility for product performance or designs as actually constructed. Because engineered wood product performance requirements vary geographically, consult your local architect, engineer or design professional to assure compliance with code, construction, and performance requirements.*

Form No. S300F  
Revised June 2002/0010

